



FULL BODY PROTECTION KIT WASHING INSTRUCTIONS

THREE COMPARTMENT SINK

1. WASH 2. RINSE 3. SANITIZE 4. DRY

1. Submerge all items into wash sink, scrub debris off. Flush inside of gloves with water.
2. Submerge all items into rinse sink. Flush inside of gloves with water.
3. Submerge all items into sanitation sink (sanitize per instructions of sanitizing agent).
4. Hang to dry. For faster drying of the gloves invert gloves so that liner is on the outside.



VAPORGUARD™
PROTECTIVE BARRIER



Certified Liquid &
Vapor Barrier

